



IMPORTANT NOTE:

1. BASEPLATES MUST BE IN FULL CONTACT WITH THE CONCRETE FLOOR OR EXCESSIVE MOVEMENT IN THE MEZZANINE WILL BE EXPERIENCED.
2. DO NOT USE WASHERS OR SMALL SHIMS UNDER THE BASEPLATES. IF SHIMMING IS REQUIRED SEE SHEET #1 MEZZANINE NOTE #2 AND USE NON-SHRINK GROUT.
3. IF THE BASEPLATE HAS ANY AIR GAP BETWEEN IT AND THE FLOOR, THEN GROUTING WILL BE REQUIRED.

TYPICAL BASE PLATE ANCHORING DETAIL